



Torque vs. Pressure Chart (for STR-30 Torque Wrench)

Gauge Pressure Reading	Applied Torque	Gauge Pressure Reading	Applied Torque
100	61	2900	1760
200	121	3000	1821
300	182	3100	1882
400	243	3200	1942
500	304	3300	2003
600	364	3400	2064
700	425	3500	2125
800	486	3600	2185
900	546	3700	2246
1000	607	3800	2307
1100	668	3900	2367
1200	728	4000	2428
1300	789	4100	2489
1400	850	4200	2549
1500	911	4300	2610
1600	971	4400	2670
1700	1032	4500	2732
1800	1093	4600	2792
1900	1153	4700	2853
2000	1214	4800	2914
2100	1275	4800	2974
2200	1335	5000	3035
2300	1396	5100	3096
2400	1457	5200	3156
2500	1518	5300	3217
2600	1578	5400	3278
2700	1639	5500	3339
2800	1700		