

## Tractor Bending Shoes Padded



Nominal Pipe Size inches (mm)	Bending Shoes inches (mm)	Length inches (mm)	Width inches (mm)	Height inches (mm)	Weight lbs. (kg)
4 (114)	4 (114)	9 (229)	29 (737)	15 (381)	140 (64)
6 (168)	6 (168)	9 (229)	29 (737)	15 (381)	141 (65)
8 (219)	8 (219)	11 (279)	29 (737)	15 (381)	165 (74)
10 (273)	10 (273)	11 (279)	29 (737)	16 (406)	216 (98)
12 (324)	12 (324)	13 (305)	29 (737)	20 (508)	249 (114)
14 (356)	14 (356)	13 (330)	29 (737)	23 (584)	290 (131)
16 (406)	16 (406)	14 (356)	29 (737)	26 (660)	337 (153)
mount w/plate (for all sizes)		20 (508)	25 (635)	29 (635)	406 (184)

Mount assembly consist of a plate, mount pin, rail and springs, and is used with all pipe sizes.