

Square Foot of Area

Valves and Fittings

Valves		Fittings	
Size (Inches)	Square Feet	Size (Inches)	Square Feet
2	6	2	3
3	9	3	4
4	12	4	5
5	15	5	6
6	17	6	7
8	23	8	9
10	28	10	11
12	34	12	13
14	37	14	15
16	42	16	17
18	49	18	20